

Toyota Tacoma 2024-2026 Tailgate Assist

ONE PAGE INSTALLATION GUIDE



IMPORTANT Park on level ground, switch off the ignition, engage the parking brake, and fully open the tailgate.

1 Remove the upper cable bolt



On the driver side, support the tailgate and remove the factory bolt securing the support cable.

2 Install the supplied flat-head bolt



If the factory bolt protrudes, replace it with the supplied low-profile bolt and tighten it securely. (Not necessary for all models.)

3 Install the upper mounting stud



Install the upper stud, reattach the support cable, press the upper damper socket onto the stud, and fit the C-clip with pliers.

4 Remove the lower factory bolt



Remove the lower bolt beside the hinge plate on the driver side.

5 Install the lower mounting stud



Install the lower stud, press the lower damper socket onto it, and secure the connection with the C-clip.

6 Check operation



Slowly open and close the tailgate several times. Confirm smooth damping, secure fasteners, and no interference.

TOOLS Socket wrench and pliers

HARDWARE NOTE Extra bolts, C-clips are included as spares.